

# KICKER

**EB54 OWNER'S MANUAL**  
**EB54 MANUAL DEL PROPIETARIO**  
**EB54 HANDBUCH**  
**NOTICE D'UTILISATION EB54**

## ⚠ WARNING!

Exposure to excessive sound levels can cause permanent hearing damage.

Keep out of reach of children. The content of this package includes small parts and cords that can cause choking or strangulation.

If an eardrum or eardrum tip becomes lodged in the ear canal, seek professional medical assistance for its removal.

Never pull on the cord to remove the earbuds. Use a slow twisting motion to remove from ear.

## ⚠ ¡ADVERTENCIA!

La exposición a niveles sonoros excesivos puede causar daños auditivos permanentes. Mantenga alejado de los niños. El contenido de esta caja incluye piezas pequeñas y cables que pueden causar asfixia o estrangulamiento.

Si un auricular o extremo de auricular queda atascado en el canal auditivo, busque ayuda médica profesional para quitarlo.

No tire del cable para quitarse los auriculares. Gírelos lentamente para quitarlos de los oídos.

## ⚠ WARNUNG!

Ohrhörer können sehr hohe Schallpegel erzeugen, welche zu permanenten Hörschäden führen können.

Außerhalb der Reichweite von Kindern aufbewahren. Diese Verpackung enthält Kleinteile an denen sie erstickten und Kabel mit denen sie sich strangulieren können.

Wenn ein Ohrhörer oder ein Stöpsel im Gehörkanal festsetzt, suchen Sie ärztliche Hilfe auf, um diesen zu entfernen.

Ziehen Sie zum Entfernen der Ohrhörer niemals am Kabel. Drehen Sie die Ohrhörer leicht, um sie aus dem Ohr zu entfernen.

## ⚠ AVERTISSEMENT !

Une exposition à des niveaux sonores excessifs peut provoquer des dégâts permanents pour l'ouïe.

Conserver hors de portée des enfants. Ce conditionnement comprend des petites pièces et des cordons risquant d'étouffer ou d'étrangler les enfants.

Si une oreillette ou une pointe d'oreillette se bloque dans le canal auditif, consulter une assistance médicale professionnelle pour la retirer.

Ne jamais tirer sur le cordon pour retirer les oreillettes. Effectuer un lent mouvement de torsion pour le sortir de l'oreille.

EB54-C-20190125


# KICKER ENGLISH VERSION

## STEREO IN-EAR MONITORS

WITH MICROPHONE AND MULTI-FUNCTION BUTTON

### EB54 OWNER'S MANUAL

The Kicker EB54 in-ear headphones feature a microphone and a multi-function button to give you control of compatible media devices.



Multi-Function Button & Microphone

Three sizes of tips included!



	iOS	Android
▶/	▶/	▶/
x2	▶▶	
x3	◀◀	
x4	📶	📶

#### EB54 Earbud Specifications

Frequency Response, Hz	27-20k	Weight/Mass, oz (g)	.53 (15)
Sensitivity, dB/1mW	98 ± 5	Speaker Diameter, in (mm)	.39 (10)
Nominal Impedance, ohm	160 ± 15%	Max Input Power, mW	5
Cord Length, in (cm)	53.15 (135)	Max Output, dB	110
Plug Type, in (mm)	3.5mm stereo with microphone		
Magnet Material	Neodymium Iron Boron (Nd-Fe-B) Magnet		
<b>Microphone:</b>	Response, Hz 50-10k ± 10dB	Impedance, 2 Ohms	Sensitivity, -42dB ± 3


# KICKER VERSIÓN ESPAÑOL

## AURICULARES ESTÉREO

CON MICRÓFONO UN BOTÓN MULTIFUNCIÓN

### EB54 MANUAL DEL PROPIETARIO

Los auriculares internos Kicker EB54 presentan un micrófono y un botón multifunción que le permiten controlar otros dispositivos de soporte compatibles.



Botón Multifunción & Micrófono

Incluye tres tamaños de almohadillas



	iOS	Android
▶/	▶/	▶/
x2	▶▶	
x3	◀◀	
x4	📶	📶

#### EB54 Especificaciones de auricular

Respuesta en frecuencia, Hz	27-20k	Peso/Masa, oz (g)	0.53 (15)
Sensibilidad, dB/1mW	98 ± 5	Dímetro del altavoz, in (mm)	0.39 (10)
Impedancia nominal, ohmios	160 ± 15%	Potencia máx. de entrada, mW	5
Longitud de cable, in (cm)	53.15 (135)	Salida máxima, dB	110
Tipo de conector, in (mm)	3.5mm estéreo con micrófono		
Material del imán	Imán de neodimio-hierro-boro (Nd-Fe-B)		
<b>Micrófono:</b>	Respuesta, Hz 50-10k ± 10dB	Impedancia, 2 Ohms	Sensibilidad, -42dB ± 3

# KICKER DEUTSCHE VERSION


## STEREO IM-OHR-KOPFHÖRER

MIT MIKROFON UND MULTIFUNKTIONSTASTE

### EB54-HANDBUCH

Die Kicker EB54 Im-Ohr-Kopfhörer verfügen über ein Mikrofon und einen Multifunktionstaste, um Ihnen die volle Kontrolle über Ihre kompatiblen Mediengeräte zu geben.

Multifunktionstaste & Mikrofon



Einschließlich drei Stöpselgrößen



	iOS	Android

#### EB54 Ohrhörer - Technische Daten

Frequenzbereich, Hz	27 - 20 k	Gewicht, oz (g)	0,53 (15)
Empfindlichkeit, dB/1 mW	98 ± 5	Lautsprecherdurchmesser, mm	15
Nennimpedanz, Ohm	160 ± 15%	Max. Eingangsleistung, mW	5
Kabellänge, Zoll (cm)	53,15 (135)	Max. Ausgang, dB	110
Stecker, Zoll (mm)	3,5mm stereo mit mikrofon		
Magnetisches Material	Neodym-Eisen-Bor (Nd-Fe-B) Magnet		
<b>Mikrofon:</b>	Frequenzbereich, Hz: 60-10 k ± 10dB	Nennimpedanz, 2 Ohms	Empfindlichkeit, -42dB ± 3

# KICKER VERSION FRANÇAISE


## ÉCOUTEURS INTRA AURICULAIRES STEREO

AVEC MICROPHONE ET D'UNE TOUCHE MULTIFONCTION

### NOTICE D'UTILISATION EB54

Les écouteurs intra auriculaires Kicker EB54 sont dotés d'un microphone et d'une touche multifonction vous permettant de commander des appareils multimédias compatibles.

Touche Multifonction & Microphone



Trois tailles d'embouts d'oreillette incluses



	iOS	Android

#### Spécifications de l'oreillette EB54

Réponse en fréquence, Hz	27-20k	Poids/masse, onces (g)	0,53 (15)
Sensibilité, dB/1mW	98 ± 5	Diamètre de haut-parleur, pouces (mm)	0,39 (10)
Impédance nominale, ohms	160 ± 15%	Puissance d'entrée maximale, mW	5
Longueur de cordon, pouces (cm)	53,15 (135)	Sortie max, dB	110
Type de fiche, pouces (mm)	stéréo 3,5mm avec microphone		
Matériau d'aimant	Aimant néodyme-fer-bore (Nd-Fe-B)		
<b>Microphone:</b>	Réponse, Hz: 50-10k ± 10dB	Impédance, 2 Ohms	Sensibilité, -42dB ± 3

### Home Limited Warranty

KICKER warrants this product to be free from defects in material and workmanship under normal use for a period of ONE (1) YEAR from date of original purchase with the original receipt from an Authorized KICKER Dealer. Should service be necessary under this warranty for any reason due to manufacturing defect or malfunction during the warranty period, KICKER will repair or replace (at its discretion) the defective merchandise with equivalent merchandise at no charge. Warranty replacements may have cosmetic scratches and blemishes. Discontinued products may be replaced with more current equivalent products.

This warranty is valid only for the original purchaser and is not extended to owners of the product subsequent to the original purchaser. Any applicable implied warranties are limited in duration to a period of the express warranty as provided herein beginning with the date of the original purchase at retail, and no warranties, whether express or implied, shall apply to this product thereafter. Some states do not allow limitations on implied warranties, therefore these exclusions may not apply to you. This warranty gives you specific legal rights; however you may have other rights that vary from state to state.

#### WHAT TO DO IF YOU NEED WARRANTY OR SERVICE

Defective merchandise should be returned to your local Authorized KICKER Dealer for warranty service. Assistance in locating an Authorized Dealer can be found at [www.kicker.com](http://www.kicker.com) or by contacting KICKER directly.

If it becomes necessary for you to return defective merchandise directly to Stillwater Designs (KICKER), call the KICKER Customer Service Department at (405) 624-8510 for a Return Merchandise Authorization (RMA) number. Package all defective items in the original container or in a package that will prevent shipping damage, and return to:

Stillwater Designs, 3100 North Husband Street, Stillwater, OK 74075

The RMA number must be clearly marked on the outside of the package. Include a copy of the original receipt with the purchase date clearly visible, and a "proof-of-purchase" statement listing your name and return shipping address, the Dealer's name and invoice number, and product purchased. Warranty expiration on items without proof-of-purchase will be determined from the type of sale and manufacturing date code. Freight must be prepaid; items sent freight-collect, or COD, will be refused.

#### WHAT IS NOT COVERED?

This warranty is valid only if the product is used for the purpose for which it was designed.

It does not cover:

- o Damage due to improper use.
- o Damage due to improper installation of components or audio/video devices.
- o Subsequent damage to other components or audio/video devices.
- o Damage caused by exposure to moisture, excessive heat, chemical cleaners, and/or UV radiation.
- o Damage through negligence, misuse, flood, fire, earthquake, accident, or abuse. Repeated returns for the same damage may be considered abuse.
- o Items previously repaired or modified by any unauthorized repair facility or person.
- o Return shipping on non-defective items.
- o Products with tampered or missing barcode labels.
- o Products returned without a Return Merchandise Authorization (RMA) number.
- o Freight Damage.
- o The cost of shipping product to KICKER.
- o Service performed by anyone other than KICKER.

#### HOW LONG WILL IT TAKE?

Kicker strives to maintain a goal of 48-hour service for all electronics returns. Delays may be incurred if lack of replacement inventory or parts is encountered.

Failure to follow these steps may void your warranty. Any questions can be directed to the Kicker Customer Service Department at (405) 624-8510.

#### GARANTÍA INTERNACIONAL VersiónEspañol

Comuníquese con su concesionario o distribuidor Kicker internacional para obtener información sobre procedimientos específicos relacionados con las normas de garantía de su país.

#### INTERNATIONALE GARANTIE DeutscheVersion

Nehmen Sie mit Ihren internationalen Kicker-Fachhändler oder Vertrieb Kontakt auf, um Details über die Garantieleistungen in Ihrem Land zu erfahren.

#### GARANTIE INTERNATIONALE VersionFrançaise

Pour connaître les procédures propres à la politique de garantie de votre pays, contactez votre revendeur ou distributeur international Kicker.