



## NMEA Feature and Compatibility Chart

	Lowrance	Simrad	Garmin GPSmap	Garmin EchoMap	Ray Marine
Does KMC show up as media player?	Yes	Yes	Yes	No	No
Power KMC Off from MFD	Yes	Yes	Yes	No	No
Power KMC On from MFD	Yes	Yes	Yes	No	No
Control Audio Source	Yes	Yes	Yes	No	No
Audio Source Names show correctly (ie. DAB, Pandora)	Yes	Yes	No	No	No
Volume Control (Zone 1/2/ALL)	Yes	Yes	Yes	No	No
Volume Mute	Yes	Yes	Yes	No	No
Balance	Yes	Yes	No	No	No
Fader	No	No	No	No	No
Set EQ (Off,Rock, Pop, Jazz, Custom)	No	No	No	No	No
Subwoofer	Yes	Yes	No	No	No
Bass	Yes	Yes	No	No	No
Middle	Yes	Yes	No	No	No
Treble	Yes	Yes	No	No	No
Bluetooth scan/pair new device	Yes	Yes	No	No	No
Bluetooth show track name	Yes	Yes	Yes	No	No
Bluetooth show artist name	Yes	Yes	Yes	No	No
Bluetooth show album name	No	No	Yes	No	No
Bluetooth Play/Pause ,Track FWD/Back	Yes	Yes	Yes	No	No
Bluetooth Fast-forward/Rewind	No	No	No	No	No
FM Seek	Yes	Yes	Yes	No	No
FM Tune	Yes	Yes	Yes	No	No
Select FM Favorite	Yes	No	No	No	No
Save FM Favorite	Yes	Yes	No	No	No
Set FM Tuner Region (USA/EU)	Yes	Yes	No	No	No
FM RDS Data shows correctly	No	No	Yes	No	No
USB Browse Track List	Yes	Yes	No	No	No
USB show track name	Yes	Yes	Yes	No	No
USB show artist name	Yes	Yes	Yes	No	No
USB show album name	No	No	Yes	No	No
USB Track Forward/Back	Yes	Yes	Yes	No	No
USB Fast-forward/Rewind	Yes	Yes	No	No	No
USB Repeat Feature	Yes	Yes	Yes	No	No
USB Shuffle Feature	Yes	Yes	Yes	No	No
Pandora Play/Pause , Next Track	Yes	Yes	No	No	No
Pandora Fast-forward/Rewind	No	No	No	No	No
Pandora Song Info (Track, Artist)	Yes	Yes	No	No	No
Pandora Thumbs Up/Down	Yes	Yes	No	No	No
Pandora Station List - See and Select Lists	Yes	Yes	No	No	No