

KICKER®

MICROFIT OWNER'S MANUAL MICROFIT MANUAL DEL PROPIETARIO MICROFIT HANDBUCH NOTICE D'UTILISATION MICROFIT

⚠️ WARNING!

Exposure to excessive sound levels can cause permanent hearing damage.

Keep out of reach of children. The content of this package includes small parts and cords that can cause choking or strangulation.

If an earbud or earbud tip becomes lodged in the ear canal, seek professional medical assistance for its removal.

Never pull on the cord to remove the earbuds. Use a slow twisting motion to remove from ear.

⚠️ WARNUNG!

Ohrhörer können sehr hohe Schallpegel erzeugen, welche zu permanenten Hörschäden führen können.

Außerhalb der Reichweite von Kindern aufbewahren. Diese Verpackung enthält Kleinteile an denen sie ersticken und Kabel mit denen sie sich strangulieren können.

Wenn ein Ohrhörer oder ein Stöpsel im Gehörkanal festsetzt, suchen Sie ärztliche Hilfe auf, um diesen zu entfernen.

Ziehen Sie zum Entfernen der Ohrhörer niemals am Kabel. Drehen Sie die Ohrhörer leicht, um sie aus dem Ohr zu entfernen.

⚠️ ¡ADVERTENCIA!

La exposición a niveles sonoros excesivos puede causar daños auditivos permanentes. Mantenga alejado de los niños. El contenido de esta caja incluye piezas pequeñas y cables que pueden causar asfixia o estrangulamiento.

Si un auricular o extremo de auricular queda atascado en el canal auditivo, busque ayuda médica profesional para quitarlo.

No tire del cable para quitarse los auriculares. Gírelos lentamente para quitarlos de los oídos.

⚠️ AVERTISSEMENT !

Une exposition à des niveaux sonores excessifs peut provoquer des dégâts permanents pour l'ouïe.

Conserver hors de portée des enfants. Ce conditionnement comprend des petites pièces et des cordons risquant d'étouffer ou d'étrangler les enfants.

Si une oreillette ou une pointe d'oreillette se bloquent dans le canal auditif, consulter une assistance médicale professionnelle pour la retirer.

Ne jamais tirer sur le cordon pour retirer les oreillettes. Effectuer un lent mouvement de torsion pour le sortir de l'oreille.

Microfit-B-20151204

KICKER® ENGLISH VERSION

STEREO IN-EAR MONITORS WITH MICROPHONE AND MULTI-FUNCTION BUTTON


MICROFIT OWNER'S MANUAL

The Kicker **Microfit** in-ear headphones feature a microphone and a multi-function button to give you control of compatible media devices.

The **Microfit** is made with a light-weight, comfortable fit for extended listening sessions in ears of all sizes.

iOS Android

33% Smaller



Microfit Earbud Specifications

Frequency Response, Hz	23-19.5k	Max Output, dB	110 @ 10mW
Sensitivity, dB/1mW	100	Speaker Diameter	8mm
Nominal Impedance, ohm	16	Cord Length, in (cm)	53.15 (135)
Cable Type	Tangle free, braided TPE cable		
Plug Type	3.5mm stereo		

KICKER® VERSIÓN ESPAÑOL

AURICULARES ESTÉREO CON MICRÓFONO Y UN BOTÓN MULTIFUNCIÓN


MICROFIT MANUAL DEL PROPIETARIO

Los auriculares internos Kicker **Microfit** presentan un micrófono y un botón multifunción que le permiten controlar otros dispositivos de soporte compatibles.

Los **Microfit** están hechos para ofrecer un ajuste cómodo y son muy ligeros lo cual permite sesiones de audio prolongadas para los oídos de todos los tamaños.

iOS Android

33% más pequeños



Microfit Especificaciones de auricular

Respuesta en frecuencia, Hz	23-19.5k	Salida máxima, dB	110 @ 10mW
Sensibilidad, dB/1mW	100	Diámetro del altavoz	8mm
Impedancia nominal, ohmios	16	Longitud de cable, in (cm)	53.15 (135)
Tipo de cable	Sin enredos, trenzado de cable TPE		
Tipo de conector	3.5mm estéreo		


KICKER® DEUTSCHE VERSION

IM-OHR-KOPFHÖRER MIT MIKROFON UND MULTIFUNKTIONSTASTE


MICROFIT-HANDBUCH

Die Kicker **Microfit** Im-Ohr-Kopfhörer verfügen über ein Mikrofon und einen Multifunktionsstaste, um Ihnen die volle Kontrolle über Ihre kompatiblen Mediengeräte zu geben.

Der **Microfit** zeichnet sich durch ein leichtes Gewicht und einen hohen Tragekomfort für ausgedehntes Hörvergnügen für Ohren aller Größen aus.



33 % Kleiner



Microfit Ohrhörer - Technische Daten

Frequenzbereich, Hz	23 - 19,5k	Max. Ausgang, dB	110 @ 10mW
Empfindlichkeit, dB/1 mW	100	Lautsprecherdurchmesser	8mm
Nennimpedanz, Ohm	16	Kabellänge, Zoll (cm)	53,15 (135)
Kabeltyp	Verwirren-frei, geflochten TPE-Kabel.		
Stecker	3,5mm stereo		


KICKER® VERSION FRANÇAISE

ÉCOUTEURS INTRA AURICULAIRES AVEC MICROPHONE ET D'UNE TOUCHE MULTIFONCTION


NOTICE D'UTILISATION MICROFIT

Les écouteurs intra auriculaires Kicker **Microfit** sont dotés d'un microphone et d'une touche multifonction vous permettant de commander des appareils multimédias compatibles.

Le dispositif **Microfit** est léger et s'adapte confortablement dans les oreilles de toute taille. pour une écoute prolongée.



Taille réduite de 33 %



Spécifications de l'oreillette Microfit

Réponse en fréquence, Hz	23-19,5k	Sortie maxi, dB	110 @ 10mW
Sensibilité, dB/1mW	100	Diamètre de haut-parleur	8mm
Impédance nominale, ohms	16	Longueur de cordon, po (cm)	53,15 (135)
Type de câble	Tangle libre, TPE tressé câble.		
Type de fiche	stéréo 3,5mm		

Home Limited Warranty

KICKER warrants this product to be free from defects in material and workmanship under normal use for a period of ONE (1) YEAR from date of original purchase with the original receipt from an Authorized KICKER Dealer. Should service be necessary under this warranty for any reason due to manufacturing defect or malfunction during the warranty period, KICKER will repair or replace (at its discretion) the defective merchandise with equivalent merchandise at no charge. Warranty replacements may have cosmetic scratches and blemishes. Discontinued products may be replaced with more current equivalent products.

This warranty is valid only for the original purchaser and is not extended to owners of the product subsequent to the original purchaser. Any applicable implied warranties are limited in duration to a period of the express warranty as provided herein beginning with the date of the original purchase at retail, and no warranties, whether express or implied, shall apply to this product thereafter. Some states do not allow limitations on implied warranties; therefore these exclusions may not apply to you. This warranty gives you specific legal rights; however you may have other rights that vary from state to state.

WHAT TO DO IF YOU NEED WARRANTY OR SERVICE

Defective merchandise should be returned to your local Authorized KICKER Dealer for warranty service. Assistance in locating an Authorized Dealer can be found at www.kicker.com or by contacting KICKER directly.

If it becomes necessary for you to return defective merchandise directly to Stillwater Designs (KICKER), call the KICKER Customer Service Department at (405) 624-8510 for a Return Merchandise Authorization (RMA) number. Package all defective items in the original container or in a package that will prevent shipping damage, and return to:

Stillwater Designs, 3100 North Husband, Stillwater, OK 74075

The RMA number must be clearly marked on the outside of the package. Include a copy of the original receipt with the purchase date clearly visible, and a "proof-of-purchase" statement listing your name and return shipping address, the Dealer's name and invoice number, and product purchased. Warranty expiration on items without proof-of-purchase will be determined from the type of sale and manufacturing date code. Freight must be prepaid; items sent freight-collect, or COD, will be refused.

WHAT IS NOT COVERED?

This warranty is valid only if the product is used for the purpose for which it was designed.

It does not cover:

- o Damage due to improper use.
- o Damage due to improper installation of components or audio/video devices.
- o Subsequent damage to other components or audio/video devices.
- o Damage caused by exposure to moisture, excessive heat, chemical cleaners, and/or UV radiation.
- o Damage through negligence, misuse, flood, fire, earthquake, accident, or abuse. Repeated returns for the same damage may be considered abuse.
- o Items previously repaired or modified by any unauthorized repair facility or person.
- o Return shipping on non-defective items.
- o Products with tampered or missing barcode labels.
- o Products returned without a Return Merchandise Authorization (RMA) number.
- o Freight Damage.
- o The cost of shipping product to KICKER.
- o Service performed by anyone other than KICKER.

HOW LONG WILL IT TAKE?

Kicker strives to maintain a goal of one-week service for all electronics returns. Delays may be incurred if lack of replacement inventory or parts is encountered.

Failure to follow these steps may void your warranty. Any questions can be directed to the Kicker Customer Service Department at (405) 624-8510.

GARANTÍA INTERNACIONAL Versión Español

Comuníquese con su concesionario o distribuidor Kicker internacional para obtener información sobre procedimientos específicos relacionados con las normas de garantía de su país.

INTERNATIONALE GARANTIE Deutsche Version

Nehmen Sie mit Ihrem internationalen Kicker-Fachhändler oder Vertrieb Kontakt auf, um Details über die Garantieleistungen in Ihrem Land zu erfahren.

GARANTIE INTERNATIONALE Version Française

Pour connaître les procédures propres à la politique de garantie de votre pays, contactez votre revendeur ou distributeur international Kicker.