

MKICKER

50KTWS3: TRUE WIRELESS HYBRID ACTIVE NOISE CANCELLING EARBUDS QUICK-START GUIDE

50KTWS3: AUDÍFONOS HÍBRIDOS VERDADERAMENTE INALÁMBRICOS CON CANCELACIÓN ACTIVA DE RUIDO INICIO RÁPIDO













Scan here for owner's manual

Escanee aquí para manual del Propietario









Quitar para activar. El modo ANC está activado de forma predeterminada.



3



Select "TWS3 KICKER" to pair. Seleccione "TWS3 KICKER" para emparejar.













Insert earbud, and gently turn while pushing. If fitment is unsatisfactory, please try a different ear tip.

Inserte el auricular y gírelo suavemente mientras empuja. Si el accesorio no es satisfactorio, pruebe con una punta de oreja diferente.



Active Noise

Cancellation only

earbuds are on.

La cancelación

está disponible

cuando ambos auriculares están

encendidos.

Power on only

Sólo encender

available when both

activa de ruido solo

FCC CAUTION

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC PILLES. OPERATION IS SUBJECT TO THE FOLLOWING TWO

(1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND(2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

ANY CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE

FCC RE EXPOSURE WARNING STATEMENT

THIS EQUIPMENT COMPLIES WITH FCC PADIATION EXPOSURE LIMITS SET FORTH FOR AN UNCONTROLLED. ENVIRONMENT, THIS EQUIPMENT CAN BE USED IN PORTABLE EXPOSURE CONDITIONS.

THE EQUIPMENT OFF AND ON, THE USER IS ENCOURAGED TO TRY TO CORRECT THE INTERFERENCE BY ONE OR MORE OF THE FOLLOWING MEASURES:

-RECRENT OR RELOCATE THE RECEIVING ANTENNA.

INCREASE THE SEPARATION BETWEEN THE EQUIPMENT AND RECEIVER.

-CONNECT THE EQUIPMENT INTO AN OUTLET ON A OPCUIT DIFFERENT FROM THAT TO WHICH THE PECEMER IS

-CONSULT THE DEALER OR AN EXPERIENCED RADIO/TV TECHNICIAN FOR HELP.


FCC ID: RGR-KTWS3





Squeeze and twist to remove tip. Apriete y gire para quitar la punta.





0 0 0

Audio Teléfono Encender

See owner's manual for

Consulte el manual del

propietario para obtener

restablecer el dispositivo.

estuche para apagarlos.

Devuelva los auriculares al

Phone

instrucciones para

power off.

earbud reset instructions.

Return earbuds to case to





Stillwater Designs

Stillwater, OK 74075

+1 (405) 624-8510













