




## Hybrid ANC+ENC True Wireless Earphones Model: TWS3





User Manual

Thanks for purchasing and using this product. For best experience, please read this manual first and also refer to the manual of your mobilephone/electronic product.



charging case indicator



Type-C charging port



Indicator

Touch Functional Area

Mic

### Product Specification

Model No.: TWS3  
Bluetooth Version: V5.3  
Music Playing Time(volume 70%): 4.5H  
Standby Time: approx. 90 days  
Charging Time(Earphone): approx. 40 mins  
Charging Time(Charging case): approx. 120 mins  
Charging Case Battery Capacity: 470mAh  
Charging Case Rated Input: DC 5V 360mA

Charging Interface: USB-C  
Earphone Capacity: 30mAh  
Earphone Rated Input: 60mA(2C fast charging)  
Communicated Distance: ≤10M  
Support Profile: A2DP/AVRCP/HFP/SPP/AAC/SBC  
Compatible with: Most of Wireless Devices  
Size(approx.): 61x50x25mm  
Total Weight: approx. 45g

### Packing List

Charging case x1  
Earphones(L & R) x2  
Eartips(S & L) x4  
Charging cable x1  
User Manual x1

### Operation Instruction

Power on:

1. Open the charging case and it turns on automatically
2. Long press and hold for 3 seconds

Power off: Put the earphones into the charging case

1. Put it in the charging case to charge and shut down, the red light of the earphone is always on(charging)
2. Overtime power off (5 minutes)/ low power off, the red light is on for 1s

Play/Pause: Double tap the left or right earphone

Previous song: Long-Tap left earphone for 1.5s

Next song: Long-Tap right earphone for 1.5s

Answer/Hang up: Double tap the left or right earphone

Reject a call: Long-Tap the left or right earphone for 2s

Activate the voice assistant: Triple-tap the left earphone

### ANC/ENC mode

Triple-tap the right earphone, the mode can be turned on from ANC ON → ANC OFF → Transparency mode → ANC ON.....

ANC ON when both earphones are turned on;  
ENC ON when both earphones are turned on

### Reset (Clear pairing record):

1. Press and hold for 5s in the pairing status to clear the pairing information of the mobile phone (the red and white lights are on for 1s)
2. The pairing record of the left and right earphones is locked, and it cannot be paired with other earphones to one pair

### Charging Indicator

1. The charging case is used to charge the earphones:  
During charging: The red indicator of the earphone is steady on  
Fully Charged: The indicator of the charging case/earphone is off

2. The charging case is connected to the power supply for charging:  
During charging: The red light is flashing  
Fully Charged: The red light is steady on

### Product safety information

Please read all instructions and warnings before using this product.  
Improper use will damage the product or personal safety.

1. The product contains batteries, please do not expose to sunlight, fire or similar overheating environment; do not store this product in high temperature, strong light and strong magnetism. In the field environment, do not place it in other harsh environments such as fire sources. If water enters, please dry it naturally before use.

2. Improper use of the product may easily cause the product itself or may endanger personal and property safety.

3. If consumers violate the instructions of the product manual and use improperly, they will bear all the consequences themselves. The company will not be responsible for any personal and/or property damage and any legal responsibility.

4. Non-professionals are strictly prohibited from disassembling this product.

5. Avoid using electrical appliances or loads that exceed the output current of this product (the circuit will be protected, no output).

6. Avoid strong physical effects, including knocking, throwing, trampling, squeezing, etc.