

# KICKER Warhorse Install Scenarios

Below are the **MINIMUM** recommended electrical requirements and installation components to properly power the Warhorse line of amplifiers. If you have questions or need additional information, please contact KICKER technical support: support@KICKER.com or (405) 624- 8583

- WXA3600.1
  - 180-amp alternator (at idle)
  - Big Three upgrade
  - Two 0-gauge OFC power and ground
  - 400 amps of fusing (200 x 2)
  - Second battery close to amplifier
    - 80Ah or more and 800 CCA or more
- WXA1000.4 - running in three-channel mode
  - two high-pass channels and two channels bridged into 4Ω load and low-passed
    - Stock alternator
    - Big Three upgrade
    - One 0-gauge OFC power and ground
    - 200 amps of fusing
- WXA3600.1 and WXA1000.4 (WXA1000.4 must be in high-pass mode)
  - 180-amp alternator (at idle)
  - Big Three upgrade
  - WXA3600.1
    - Two 0-gauge OFC power and ground
    - 400 amps of fusing (200 x 2)
  - WXA1000.4
    - 1 0-gauge OFC power and ground
    - 200 amps of fusing
  - Second battery close to amplifiers
    - 80Ah or more and 800 CCA or more